




PREPARE THE GROUND, UNWRAP THE PACKAGE,  
LAY OUT THE COMPONENTS, FIND THE TOOLS.

# ANNA 28



4x40 × 60

4x50 × 190



5x70 × 10

6x140 × 25



M8x60 × 12

1,4x40 × 20

LAY OUT THE FOUNDATION BEAMS AND SQUARE IT BY MEASURING FROM CORNER TO CORNER.






ANNA 28



MAKE SURE THAT THE FOUNDATION IS INSTALLED ON A LEVEL SURFACE. CHECKING ALL DIRECTIONS, INCLUDING CORNER TO CORNER. 3%




LAY OUT THE **BOTTOM** LOGS,  
**ATTACH** TO THE FOUNDATION.

ANNA 28



THE WALL **LOGS** WILL HANG OVER  
THE FOUNDATION **BEAMS** BY  
**APPROXIMATELY** 5MM. THIS OVERHANG  
IS DESIGNED AS A RAIN DRIP. **5%**


ATTACH THE FIRST ROW OF  
**WALL LOGS** INTO THE BOTTOM  
LOGS WITH **SCREWS**.



ANNA 28


AFTER PLACING 3-4 ROWS OF WALL LOGS, TAP EACH WALL LOG IN PLACE USING A HAMMER AND THE HITBLOCK PROVIDED, TO TIGHTEN THE LOGS.

ANNA 28



SLIDE THE DOOR IN,  
ATTACH THE HANDLE.




ANNA 28



INSTALL THE GABLES WITH LONG SCREWS TO THE WALL LOGS ON THE FRONT AND REAR WALLS.



ANNA 28

6x140 × 4  
Ø 5 mm



INSTALL THE **ROOF** PURLINS AND **ATTACH** THEM WITH SCREWS.

6x140 × 2  
Ø 5 mm




ANNA 28

PLACE THE FIRST **ROOFBOARD** FLUSH WITH THE END OF THE **PURLINS** AND ATTACH WITH 4 SCREWS, 2 INTO **EACH** NEXT, SAW THE LAST **BOARD** TO MAKE IT FIT.

ANNA 28



4x50  × 92



INSERT FOR THE FASCIA TRIMS  
SCREWS AFTER EVERY 0,5 METERS.

ANNA 28

4x40  
× 20





EAVES EDGES GO ON TOP OF THE ROOFING\*.

\*(NOT INCLUDED)

4x40 × 28

Ø 3 mm




ANNA 28

ATTACH ROMBS WITH SCREWS.


ANNA 28

$\phi 3 \text{ mm}$   
 $4 \times 40$   $\times$  4




8 SCREWS INTO THE FIRST FLOORBOARD,  
4 INTO EACH NEXT, SAW THE  
LAST BOARD TO MAKE IT FIT.

4x50  
× 72




ANNA 28





SAW THE **BASEBOARDS**  
AND ATTACH WITH NAILS  
AT **EVERY 0,5** METERS.

1,4X40  
× 20



BB






ANNA 28

DRILL THROUGH THE WALL, HOLE MUST BE AT THE BOTTOM OF THE OVAL, ATTACH WITH BOLT.

M8x60 × 12

Ø 8 mm




WINDBOARD

ANNA 28


IF DOOR IS TILTED,  
PUSH THE DOOR FRAME SO  
THAT ALL CORNERS ARE  $90^\circ$ .

ANNA 28



IF DOOR IS NOT ON THE RIGHT HEIGHT,  
ADJUST 3 SCREWS ON DOOR HINGES.

ANNA 28



WHEN THE **HOUSE** IS ASSEMBLED, YOU SHOULD **COVER** THE TIMBER WITH **WOOD** PROTECTIVE SEAL, PAINT OR **STAIN** AS SOON AS POSSIBLE TO AVOID DETERIORATION TO THE **WOOD**.

ANNA 28

