




PREPARE THE GROUND, UNWRAP THE PACKAGE,  
LAY OUT THE COMPONENTS, FIND THE TOOLS.

# BODEN I 40



4x40 × 230

4x50 × 800

5x70 × 60



6x140 × 90

M8x70 × 24



6x160 × 10

1,4x40 × 60

LAY OUT THE FOUNDATION BEAMS AND SQUARE IT BY MEASURING FROM CORNER TO CORNER.



BODEN I 40





MAKE SURE THAT THE FOUNDATION IS INSTALLED ON A LEVEL SURFACE. CHECKING ALL DIRECTIONS, INCLUDING CORNER TO CORNER. 1%

# ATTACH FOUNDATION BEAMS WITH SCREWS.




BODEN I 40

6x140  
×12  
Ø 5 mm




LAY OUT THE **BOTTOM** LOGS,  
**ATTACH** TO THE FOUNDATION.

BODEN I 40





THE WALL **LOGS** WILL HANG OVER  
THE FOUNDATION **BEAMS** BY  
**APPROXIMATELY** 5MM. THIS OVERHANG  
IS DESIGNED AS A RAIN DRIP. **3%**

ATTACH THE FIRST ROW OF WALL LOGS INTO THE BOTTOM LOGS WITH SCREWS.




BODEN I 40





AFTER PLACING 3-4 ROWS OF WALL LOGS, TAP EACH WALL LOG IN PLACE USING A HAMMER AND THE HITBLOCK PROVIDED, TO TIGHTEN THE LOGS.

BODEN I 40




SLIDE THE DOOR IN,  
ATTACH THE HANDLE.

BODEN I 40




DON`T FORGET TO  
**TIGHTEN** THE LOGS AFTER  
EVERY 3-4 ROWS.


BODEN I 40




SLIDE THE WINDOW IN,  
ATTACH THE HANDLE.

BODEN I 40









INSTALL THE **CEILING** BEAMS AND **ATTACH** THEM WITH SCREWS.

6x140 × 4  
Ø 5 mm





BODEN I 40



INSTALL THE BEAM AND ATTACH WITH SCREWS.

BODEN I 40



5x70 × 15  
Ø 4 mm




INSTALL THE GABLES WITH LONG SCREWS TO THE WALL LOGS ON THE FRONT AND REAR WALLS.

6x140 × 4

Ø 5 mm





BODEN I 40



INSTALL THE **ROOF** PURLINS AND **ATTACH** THEM WITH SCREWS.


BODEN I 40

6x160 × 10  
Ø 5 mm




PLACE THE FIRST **ROOFBOARD** FLUSH WITH THE END OF THE **PURLINS** AND ATTACH WITH 8 SCREWS, 4 INTO **EACH** NEXT, SAW THE LAST **BOARD** TO MAKE IT FIT.

4x50  × 368




BODEN I 40



FOR THE FASCIA TRIMS INSERT  
SCREWS AFTER EVERY 0,5 METERS.

BODEN I 40

4x40  
× 44




EAVES EDGES GO ON TOP OF THE ROOFING\*.


\*(NOT INCLUDED)

4x40

Ø 3 mm




BODEN I 40



ATTACH ROMBS WITH SCREWS.


BODEN I 40

4x40  
× 4  
Ø 3 mm



12 SCREWS INTO THE FIRST FLOORBOARD,  
6 INTO EACH NEXT, SAW THE  
LAST BOARD TO MAKE IT FIT.

4x50  
× 204





BODEN I 40




10 SCREWS INTO THE FIRST FLOORBOARD,  
5 INTO EACH NEXT, SAW THE  
LAST BOARD TO MAKE IT FIT.

4x50  
× 170




BODEN I 40




SAW THE **BASEBOARDS**  
AND ATTACH WITH NAILS  
AT **EVERY 0,5** METERS.

1,4×40  
× 50




BODEN I 40




DRILL THROUGH THE WALL, HOLE MUST BE AT THE BOTTOM OF THE OVAL, ATTACH WITH BOLT.

M8x70 × 24

Ø 8 mm



BODEN I 40





WINDBOARD

ASSEMBLE THE STAIRCASE.

BODEN I 40

6x140 ×36  
Ø 5 mm



ST1R

ST1L

ST2

24/34

90%

DECIDE WHERE TO  
INSTALL THE LADDER.

BODEN I 40



SET THE LADDER IN THE RIGHT SPOT,  
ATTACH THE FIRST HALF OF THE LADDER  
FITTINGS TO THE WALL WITH SCREWS.

BODEN I 40



4x40  
×8



CONNECT THE OTHER HALF OF THE LADDER FITTINGS AND ATTACH THEM WITH SCREWS TO THE STAIRCASE.

4x40  
× 8



BODEN I 40



# ATTACH FENCE DETAILS.

5x70  ×18


Ø 4 mm 




BODEN I 40

USE ANGLE BRACKETS TO CONNECT  
FENCE DETAILS TO PURLINS.

4x40  
×64






BODEN I 40



SAW THE FENCE DETAILS INTO RIGHT LENGTH DEPENDING ON WHERE YOU POSITIONED THE LADDER, ATTACH WITH SCREWS.

BODEN I 40



4x40  
×36



SAW THE **FENCE** DETAILS INTO RIGHT SIZE AND SHAPE, **ATTACH** WITH SCREWS.



BODEN I 40

4x50  
×16





IF DOOR IS TILTED,  
PUSH THE DOOR FRAME SO  
THAT ALL CORNERS ARE 90°.

BODEN I 40



IF DOOR IS NOT ON THE RIGHT HEIGHT,  
ADJUST 3 SCREWS ON DOOR HINGES.

BODEN I 40



WHEN THE **HOUSE** IS ASSEMBLED, YOU SHOULD **COVER** THE TIMBER WITH **WOOD** PROTECTIVE SEAL, PAINT OR **STAIN** AS SOON AS POSSIBLE TO AVOID DETERIORATION TO THE **WOOD**.

BODEN I 40

