














PREPARE THE GROUND, UNWRAP THE PACKAGE,
LAY OUT THE COMPONENTS, FIND THE TOOLS.

BRANTEVIK II 40




LAY OUT THE FOUNDATION BEAMS AND SQUARE IT BY MEASURING FROM CORNER TO CORNER.





MAKE SURE THAT THE FOUNDATION IS INSTALLED ON A LEVEL SURFACE. CHECKING ALL DIRECTIONS, INCLUDING CORNER TO CORNER. 3%

LAY OUT THE **BOTTOM** LOGS,
ATTACH TO THE FOUNDATION.

BRANTEVIK II 40

5×70  $\times 4$ 6×140  $\times 14$




$\varnothing 4 \text{ mm}$  $\varnothing 5 \text{ mm}$ 



THE WALL **LOGS** WILL HANG OVER
THE FOUNDATION **BEAMS** BY
APPROXIMATELY 5MM. THIS OVERHANG
IS DESIGNED AS A RAIN DRIP. **5%**


ATTACH THE FIRST ROW OF
WALL LOGS INTO THE BOTTOM
LOGS WITH **SCREWS**.

BRANTEVIK II 40




AFTER PLACING 3-4 ROWS OF WALL LOGS, TAP EACH WALL LOG IN PLACE USING A HAMMER AND THE HITBLOCK PROVIDED, TO TIGHTEN THE LOGS.

BRANTEVIK II 40




SLIDE THE DOOR IN,
ATTACH THE HANDLE.

BRANTEVIK II 40




DON`T FORGET TO
TIGHTEN THE LOGS AFTER
EVERY 3-4 ROWS.

BRANTEVIK II 40



SLIDE THE WINDOW IN,
ATTACH THE HANDLE.




BRANTEVIK II 40



INSTALL THE **GABLES** WITH **LONG SCREWS** TO THE WALL LOGS ON THE FRONT AND REAR WALLS.

BRANTEVIK II 40



6x140 × 4
Ø 5 mm



INSTALL THE ROOF PURLINS AND ATTACH THEM WITH SCREWS.

BRANTEVIK II 40



6x140 × 6
Ø 5 mm



PLACE THE FIRST **ROOFBOARD** FLUSH WITH THE END OF THE **PURLINS** AND ATTACH WITH 6 SCREWS, 3 INTO **EACH** NEXT, SAW THE LAST **BOARD** TO MAKE IT FIT.



BRANTEVIK II 40

4x50  × 288



FOR THE FASCIA TRIMS INSERT
SCREWS AFTER EVERY 0,5 METERS.

4x40
× 44



EAVES EDGES GO ON TOP OF THE ROOFING*.

*(NOT INCLUDED)



BRANTEVIK II 40

4x40 × 32

Ø 3 mm

RF



EE



ATTACH ROMBS WITH SCREWS.



BRANTEVIK II 40

4×40
 $\times 4$
 $\varnothing 3 \text{ mm}$





14 SCREWS INTO THE FIRST FLOORBOARD,
7 INTO EACH NEXT, SAW THE
LAST BOARD TO MAKE IT FIT.

4x50
× 238







SAW THE **BASEBOARDS**
AND ATTACH WITH NAILS
AT **EVERY 0,5** METERS.

1,4×40
× 30






WINDBOARD CONNECTS BOTTOM LOG WITH THE TOP LOG. SAW THE WINDBOARD INTO THE RIGHT LENGTH. FOR THE TOP BOLT, DRILL 8MM HOLE THROUGH THE WINDBOARD.



DRILL THROUGH THE WALL, HOLE MUST BE AT THE BOTTOM OF THE OVAL, ATTACH WITH BOLTS. 97%


IF DOOR IS TILTED,
PUSH THE DOOR FRAME SO
THAT ALL CORNERS ARE 90°.

BRANTEVIK II 40



IF **DOORS** ARE IN DIFFERENT HEIGHTS
OR THERE IS A GAP **BETWEEN** THEM,
ADJUST 3 SCREWS ON DOOR HINGES.

BRANTEVIK II 40



WHEN THE **HOUSE** IS ASSEMBLED, YOU SHOULD **COVER** THE TIMBER WITH **WOOD** PROTECTIVE SEAL, PAINT OR **STAIN** AS SOON AS POSSIBLE TO AVOID DETERIORATION TO THE **WOOD**.

BRANTEVIK II 40

